
TREE FROM LEAVES TO INSERTION POINT
TREE FROM TEMP INSERTION POINT TO SOURCE
(FIG.2)
110
READ SINK LOCATIONS & BLOCKAGE
120
GET TEMPORARY INSERTION POINT
130
RUN TREE GENERATION PROGRAM
140
(FIG.3)
PLACE TREE BY SINK & BLOCKAGE
150
(FIG.4&5)
IMPROVE SYMMETRY
160
PLACE SOURCE TO ROOT TREE
170
INSERT TREE INTO NETLIST
PLACE TREE

FIG. 1



FIG.2



FIG.3

BEST AVAILABLE COPY

10/539334
Rec'd PCT/PTO 15 JUN 2005



FIG.4

BEST AVAILABLE COPY

10/539334
Rec'd PCT/PTO 15 JUN 2005



FIG.5

BEST AVAILABLE COPY

10/539334
Rec'd PCT/PTO 15 JUN 2005



FIG.6

BEST AVAILABLE COPY